

Counting Rice Grain



Video Link:

https://www.youtube.com/watch?v=EXtKSxcZTSY&ab_channel=NorhazifaHarum

Presented By:

- Norhazifa Harum (B032020048)
- Ain Fatihah Aiman (B032020016)
- Muhammad Aiman (B032110509)

- Rice and wheat yields are mostly determined by thousand grain weight, which is an important metric for variety breeding and cultivation management.
- Counting grains is a necessary step in determining the weight of a thousand grain sample. Manual counting is tedious and time-consuming; electronic counting devices are costly; counting accuracy based on image segmentation processing is low; and their applications are inconvenient.
- This study attempts to develop a system for fast rice and wheat grain counting based on the image given.

Introduction





Problem Statement

1. Manual counting is time consuming and tedious. Human eyes can become fatigued, resulting in errors.
2. How to recognize a common rice grain.
3. How to tell the difference between regular and not-so-regular sized grains.



Objective

1. Count each rice grain individually.
2. Determine the total number of grains required to meet the standard quantity.
3. To locate the exact normal grain size.



1. Changes in Intensity
(Contrast)

2. Separation (Edge Detection)


3. Image Binarization

4. Conversion of Color Space






Technique used in the code




Methodology – Flowchart



SUMMARY OF FLOWCHART SYMBOLS

SYMBOLS	NAME	FUNCTION
	Start/end	An oval represents a start or end point
	Arrows	A line is a connector that shows relationships between the representative shapes
	Input/Output	A parallelogram represents input or output
	Process	A rectangle represents a process
	Decision	A diamond indicates a decision





1. Read the rice grains image in a PNG format.
2. Convert to gray image since we have to make binary image later.
3. Generate histogram. To get threshold value.
4. Then, we can convert to binary image.
5. Find & identify rice grains.
6. Convert to RGB to differentiate between background and the rice grains.
7. Find the area of 50th component so that we can find the smallest and largest area of rice grains.
8. Labelled the rice grains with number then displayed them in figures.
9. After labelled, find the area of labelled rice grains.
10. If the area more than 100, total value will be added to 1 and else it will added with 0.
11. Then, this phase must satisfied with both condition which if area is more than 5000 and less than 8000, standard size will be added to 1. If not, it will added with 0.
12. Lastly, if there are more grains found, the processes will be repeated, if no grains found, it will print all the figures.





Code & Demonstration



MATLAB R2022a - academic use

HOME PLOTS APPS EDITOR PUBLISH VIEW

New Open Save Compare Print Go To Find Bookmark Refactor Analyze Profiler Run Section Run and Advance Run to End Run Step Stop

FILE NAVIGATE CODE ANALYZE SECTION RUN

Current Folder: C:\3BITI SEM 2\IMAGE PROCESSING\project

Editor - C:\3BITI SEM 2\IMAGE PROCESSING\project\main.m

read.m identifyObject.m labelObject.m main.m

```
1 clc % this clear the screen
2 close all % this closes all figures
3 clear all % this clears the workspace
4
5 % Assign image into variable
6 img='rice.jpeg'
7
8 % Function: read.m file - AIN FATIHAH AIMAN BINTI MOHD YUSSUF
9 % read image, convert to greyscale, covert to binary
10 [a, I, bw ]=read(img)
11
12 % Function: identifyObject.m - MUHAMMAD AIMAN BIN REDUAN
13 [cc,grain,labeled, RGB_label]=identifyObject(bw)
14
15
16 %Computer Area-Based Statistic - NORHAZIFA BINTI HARUM
17 graindata = regionprops(cc,'basic') %display basic properties
18 grain_areas = [graindata.Area]; %holds the area measurement for each grain.
19 grain_areas(50) %Find the area of the 50th component.
20 [min_area, idx] = min(grain_areas) % the grain with the smallest area.
21 [max_area, idx] = max(grain_areas) % the grain with the largest area.
22 grain = false(size(bw));
23 grain(cc.PixelIdxList{idx}) = true;
24
25 L = bwlabel(I); % label each object
26 %Step 2: see the label of each object
27
28 %Function: labelObject.m
29 [s,k,c]=labelObject(L,I)
30
31 % Step 3: find the area of the object you want using its label
32 Total_value=0;
33 Standard=0;
34 Area_1=0;G
```

Workspace

Name	Value
------	-------

Command Window

Ready Zoom: 100% UTF-8 CRLF script Ln 8 Col 62



MATLAB R2022a - academic use

HOME

PLOTS

APPS

EDITOR

PUBLISH

VIEW

New

Open

Save

Compare

Print

Go To

Find

Bookmark

Refactor

Profiler

Analyze

Run

Section Break

Run and Advance

Run to End

Run

Stop

Run all sections (F5)

Search Documentation

NORHAZIFA

C:\38ITI SEM 2\IMAGE PROCESSING\project

Current Folder

Workspace

read.m

IdentifyObject.m

labelObject.m

main.m

```
1 clc % this clear the screen
2 close all % this closes all figures
3 clear all % this clears the workspace
4
5 % Assign image into variable
6 img='rice.jpeg'
7
8 % Function: read.m file - AIN FATIHAH AIMAN BINTI MOHD YUSSUF
9 % read image, convert to greyscale, covert to binary
10 [a, I, bw]=read(img)
11
12 % Function: identifyObject.m - MUHAMMAD AIMAN BIN REDUAN
13 [cc,grain,labeled, RGB_label]=identifyObject(bw)
14
15
16 %Computer Area-Based Statistic - NORHAZIFA BINTI HARUM
17 graindata = regionprops(cc,'basic') %display basic properties
18 grain_areas = [graindata.Area]; %holds the area measurement for each grain.
19 grain_areas(50) %Find the area of the 50th component.
20 [min_area, idx] = min(grain_areas) % the grain with the smallest area.
21 [max_area, idx] = max(grain_areas) % the grain with the largest area.
22 grain = false(size(bw));
23 grain(cc.PixelIdxList{idx}) = true;
24
25 L = bwlabel(I); % label each object
26 %Step 2: see the label of each object
27
28 %Function: labelObject.m
```

labelObject.m (Function)

NORHAZIFA BINTI HARUM

labelObject(L, I)

Units: 'points'

Show all properties

>>

Zoom: 100%

UTF-8

CRLF

script

Ln 11 Col 1





NORHAZIFA BINTI HARUM





Result & Analysis





RESULTS



RESULTS



ANALYSIS



- 1. System is easy to use.**
- 2. Reduces time used counting.**
- 3. To determine the quality of grain**



Advantages Of System



- 1. Sometimes the results are not accurate**
- 2. Rice grain cannot be close to one another**
- 3. Cannot get results if given video**



Disadvantages Of System

